Product Specifications

Viewable Graphic: 33.5" w x 78.5" h
Footprint Dimensions: 15" x 34.5"

Product Parts

1 - Base
2 - Banner Rail
3 - Shock Cord Pole
4 - Pin

## *Do Not Pull Pin Until Directed

Banner Install

Step 1

Remove all parts from the bag. Place the banner on a clean, flat surface.

Step 2

Remove both End Caps (A) from the Banner Rail and snap the Banner Rail (3) open. Fully insert the top edge of the Banner into the groove of the Banner Rail 3) and snap it shut (B).

A

Clamp Banner
Rail Shut

Insert Banner

B

Step 3

(A) Lay the banner flat, printed side up and align the banner to the top of the tape leader. (B) On the Base (1) remove the strip of protective paper to expose the adhesive while firmly and evenly pressing the bottom of the banner onto the adhesive. (C) Gently smooth out any bubbles or wrinkles where the banner and tape leader connect.

A

B

C

Step 4

Maintain tension on the banner while slowly removing the Pin (4). Allow the banner to gently roll into the canister.

**Store the Pin on the base for future graphic changes.

Step 5

Once the banner has been fully retracted into the Base, simply place the display in the carrying case until you are ready for display set-up.